

4-Axis Motor Control IC with Interpolation Function

MCX314As/AL are 4-axis motion control ICs which can independently control each 4-axis of either stepper motor driver or pulse type servo motor for position and speed control. In addition, these ICs can perform 2/3-axis linear interpolation, CW/CCW circular interpolation, CCW/CW circular interpolation, 2/3-axis bit pattern interpolation and continuous interpolation. The power voltage of MCX314As is +5V and that of MCX314AL is +3.3V.



MCX314As *3

Specification

- Control axis 4 axes
- Data bus width 16/8 bit selectable

Interpolation

2/3-axis linear interpolation, CW/CCW circular interpolation, 2/3-axis bit pattern interpolation

- Interpolation range Each axis -2,147,483,646 ~ +2,147,483,646
- Interpolation speed 1PPS ~ 4 MPPS(*1)
- Interpolation accuracy ±0.5 LSB(Linear interpolation), ±1 LSB(Circular interpolation)
- Related functions for interpolation Any axis selectable, constant vector speed, continuous interpolation, single step interpolation (Command/external signals)

Common specifications of each axis

- Drive output pulse (at CLK=16MHz) 1PPS ~ 4 MPPS *1
- Pulse output speed range ±0.1% or less(According to the setting speed)
- Pulse output speed accuracy 954 ~ 31.25×10⁶PPS/SEC²
- S-curve jerk 125 ~ 500×10⁶PPS/SEC
- Accelerating/decelerating speed 1 ~ 4×10⁶PPS
- Initial speed 1 ~ 4×10⁵PPS
- Drive speed 1 ~ 4×10⁵PPS
- Output pulse number 0 ~ 4,294,967,295(Fixed pulse drive) or Unlimited(Continuous drive)
- Speed curve

Constant speed, symmetrical/non-symmetrical linear acceleration/deceleration, symmetrical/non-symmetrical parabola S-curve acceleration/deceleration drive

- Fixed pulse drive decelerating mode
- Auto(Non-symmetrical linear acceleration/deceleration is also allowed.)/Manual
- Output-pulse numbers and drive speed are changeable during the driving.
- Triangle form prevention of linear acceleration fixed pulse drive and S-curve acceleration/deceleration fixed pulse drive.
- Independent 2-pulse system or 1-pulse 1-direction system is selectable.
- Logical levels of drive pulse is selectable, output pin is switchable.
- Encoder input
- 2-phase pulse style or Up/Down pulse style is selectable.
- Pulse of each single,double and quad count edge evaluation is selectable. (2-phase pulse style).

Position counter

- Logic position counter(for output pulse) range -2,147,483,648 ~ +2,147,483,647
- Real position counter(for feedback pulse) range -2,147,483,648 ~ +2,147,483,647
- Comparison register
- COMP+ register comparison range -2,147,483,648 ~ +2,147,483,647
- COMP- register comparison range -2,147,483,648 ~ +2,147,483,647
- Status and signal outputs for the comparisons of position counters
- To work as software limit
- Synchronous action
- Activation factor
- Position counter ≥COMP+ variation, Position counter < COMP+ variation, Position counter < COMP- variation, Position counter ≥ COMP- variation, start of driving, terminating of driving, IN3 signal ↑ and ↓, LP read command.
- Action

Start of +/- fixed pulse drive, start of +/- continuous pulse drive, drive decelerating/instant stop, saving position counter values, setting position counter, setting output pulse number, setting a drive speed, external signal output (DCC) and interrupt occurring.

Any action of other axes can be activated from the factor of the own axis.

Integral filter built-in



Equipped with integral filters in the input column of each input signal. One time constant can be selected from eight types.

- Automatic home search
- Automatic of execution of Step1(high-speed near home search) → Step2(low-speed home search) → Step3(low-speed encoder Z-phase search) → Step4(high-speed offset drive). Enable/disable and search direction for each step are selectable.
- Deviation counter clear output
- Clear pulse width within the range of 10μ ~ 20msec and logical level are selectable.
- Interrupt (Interpolations excluded)
 - the drive-pulse outputting,
 - the start/finish of a constant-speed drive during the acceleration/deceleration driving
 - the end of the driving
 - transition to "position counter ≥ the volume of COMP-
 - transition to "position counter < the volume of COMP-
 - transition to "position counter ≥ the volume of COMP+
 - transition to "position counter < the volume of COMP+
 - terminating of automatic home search, synchronous action
- Enable/disable for these factors are selectable.
- External signal for driving
- EXPP, EXPM signals for +/- direction of fixed pulse/continuous drive
- Driving in manual pulsar mode(encoder input)
- External decelerating/instant stop signal
- IN0~3 4 points for each axis
- Enable/disable and logical levels are selectable.
- Input signal for servo motor
- ALARM(Alarm), INPOS(In position check)
- DCC(Deviation counter clear, pin shared with DRIVE)
- General output signal
- OUT0~7 8 points for each axis
- (Four points of them are pin shared with drive status output signal.)
- Drive status signal output
- DRIVE(Drive pulse outputting, pin shared with DCC), ASND(accelerating), DSND(decelerating), CMPP(Position ≥ COMP+), CMPM(Position < COMP-). Drive status is readable by status registers.
- Limit signal input
- 1 point, for each +/- direction.
- Logical levels and decelerating/instant stop is selectable.
- Emergency stop signal input
- EMGN 1 point for all axes.
- Stop the drive pulse for all axes immediately in Low level.

	MCX314As	MCX314AL
Power voltage	+5V ± 5 %	+3.3V ± 10 %
Consumption current	112 mA max	30 mA max at CLK=16MHz
Clock pulse	16MHz	16MHz or 32MHz(max)
Input signal level	TTL level	TTL level (5V tolerant)
Output signal level	5V CMOS Level	3.3V CMOS Level *2
Dimension(including pins)	22×22×1.6mm	22×22×1.7mm
Package	144-pin plastic LQFP, pitch = 0.5mm lead free item	

*1 Speed range of MCX314AL becomes 2PPS ~ 8MPPS at CLK=32MHz.
 *2 Only TTL can be connected for 5V type.
 *3 Pin assignment of MCX314As and that of MCX314AL are different.


MCX314As /AL Functional Block Diagram



Note1 EMGN is for all axes use.

Individual control for 4-Axis

These MCX314As/AL have 32 bit position counter for each X,Y,Z and U axis and can control maximum speed 4MPPS(at CLK=16MHz), drive for constant speed, trapezoidal acceleration/deceleration(symmetry/non-symmetry) and S-curve acceleration/deceleration. There are two kinds of pulse drive, fixed pulse drive which outputs specified pulse number or continuous pulse drive which outputs drive pulse unlimitedly until stop factor is generated. These types of driving can be performed with constant speed, linear acceleration/deceleration(symmetry/non-symmetry), S-curve acceleration/deceleration(symmetry/non-symmetry) according to the mode setting and the operation parameter value. Automatic deceleration can be functioned on non-symmetry trapezoidal acceleration/deceleration drive. Non-symmetry S-curve drive deceleration is operated by manual.



Interpolation function

2/3-axis linear interpolation

MCX314As/AL can perform any 2/3 axes linear interpolation from 4 axes. Linear interpolation is executed by setting the speed parameters to main axis(AX1) and the finish point to each axis and writing linear interpolation drive command. Linear interpolation moves from the present point coordinates to the finish point coordinates. Its range for each axis is $-2,147,483,646 \sim +2,147,483,646$ and accuracy of specified line is $\pm 0.5LSB$ or less within the whole range. Interpolation drive speed is 1PPS~4MPPS(at CLK=16MHz).

[Setting procedure for the operation of Fig.1]

- AX1:X, AX2:Y, AX3:Z Specified
- Range R=8,000,000 (Speed multiple:1)
- Initial speed SV=1000
- Drive speed V=1000(1000PPS)
- Finish point XP=30000
- Finish point YP=40000
- Finish point ZP=50000
- 3 axes linear interpolation driving




Fig.1 Example of 3-axis linear interpolation

Continuous interpolation

Continuous interpolation executes the sequence of interpolation drive continuously. During the continuous interpolation, the driving will not stop; contrarily, the pulses are output continuously. When executing the continuous interpolation, the host CPU has to write the next interpolation segment into MCX314As/AL before the previous interpolation segment is finished.

Fig.4 shows the example of continuous interpolation from segment 1 to segment 8 of which start point is (0,0). In Segment 1,3,5 and 7, linear interpolation is executed. In segment 2,4,6 and 8, circular interpolation is executed of which track are quadrant circle with radius 1500.





Fig.4 Example of continuous interpolation


Automatic home search

The automatic home search function executes the home search sequence from step1:high-speed near home search to step4:high-speed offset drive as the following figure. Set execution/non-execution and a search direction mode for each step.




Synchronous action

Synchronous action is a function which performs the specified action such as the starting/stopping of driving, by linking with a provocative when an activation factor occurs in each axis, between some axes or with an external device. It is possible to operate accurate synchronous action since the delay time is generated very few till the action starts. Ten types of activation factors are available such as the passing of the specified position and the starting/stopping of driving so on. Fourteen types of actions are available, starting/stopping of driving, saving a position counter value, and so on.



Built-in integral filter

The signal of limit and driving stop for each axis are influenced by external noise. To cut these noises, photo coupler or CR integral filter is mounted on the circuit normally. However MCX314As/AL are equipped with integral type filters in the input stage of each input signal. It is possible to set a number of input signals whether the filter function is enabled or the signal is passed through. A filter time constant is selectable from eight stages, min.2μsec ~ max.16msec.



Circular interpolation

Any 2 axes of the 4 axes can be selected for circular interpolation. Circular interpolation is executed to write the command of CW circular interpolation or CCW circular interpolation after setting the center and the finish point to the current point(start point). CW circular interpolation is starting from the current point to the finish point with clockwise direction, to the contrary, CCW circular interpolation drives to counterclockwise direction. The perfect circle appears by setting (0,0) to the finish point. The range of interpolation coordinates is $-2,147,483,646 \sim +2,147,483,646$. The position tolerance for specified circular curve is $\pm 1LSB$ within the whole interpolation range. Interpolation drive speed is 1PPS ~ 4MPPS(at CLK=16MHz).




Fig.2 Example of CCW circular interpolation

[Setting procedure for the operation of Fig.2]

- AX1:X, AX2:Y Specified
- Range R= 8,000,000(Speed multiple:1)
- Initial speed SV= 500
- Drive speed V= 500(500PPS)
- Center point XC= -10000
- Center point YC= -10000
- Finish point XP= 0
- Finish point YP= -20000
- CCW circular interpolation driving

[Setting procedure for the operation of Fig.3]

- ~ ④ Same as Fig.2
- Center point XC= 5000
- Center point YC= 0
- Finish point XP= 0
- Finish point YP= 0
- CW circular interpolation driving




Fig.3 Example of CW circular interpolation

Synchronous action mode setting

Each bit of WR6, 7 is set as the following table and an axis assignment with the command code 64h is written in WR0 register. At resetting, all of the bits are cleared to "0".

Address			Symbol	Register name	Contents
A2	A1	A0			
1	1	0	WR6	Write data register 1	Assignment of the activation factor (Provocative) and the activation of the other axis. 1:enable/0:disable D15 D14 D13 D12 D11 D10 D9 D8 D7 D6 D5 D4 D3 D2 D1 D0 [AXIS3] [AXIS2] [AXIS1] // [CMD] [LPRD] [IN3] [IN2] [IN1] [D-END] [D-STA] [P<C-IP<C+] [P<C-IP<C+] [P<C-IP<C+] [P<C-IP<C+]
1	1	1	WR7	Write data register 2	Assignment of action(Action). 1:enable/0:disable D15 D14 D13 D12 D11 D10 D9 D8 D7 D6 D5 D4 D3 D2 D1 D0 [INT] [OUT] [0] [0] [V] [SET] [OPSET] [EPSET] [LPSET] [EPSAV] [LPSAV] [ISTOP] [SSTOP] [CDRV] [CDRV+] [FDRV] [FDRV+]

Read register

Address			Symbol	Register name	Contents
A2	A1	A0			
0	0	0	RR0	Main status register	Displaying the drive and error status of each axis and interpolation driving status. D15 D14 D13 D12 D11 D10 D9 D8 D7 D6 D5 D4 D3 D2 D1 D0 [-] [BPSC1] [BPSC0] [ZONE2] [ZONE1] [ZONE0] [CNEXT] [I-DRV] [U-ERR] [Z-ERR] [Y-ERR] [X-ERR] [U-DRV] [Z-DRV] [Y-DRV] [X-DRV]
0	0	1	XRR1 YRR1 ZRR1 URR1	X axis status register 1 Y axis status register 1 Z axis status register 1 U axis status register 1	Displaying the comparison of positoin counter and COMP± register, status of acceleration/deceleration during the driving and driving termination status. D15 D14 D13 D12 D11 D10 D9 D8 D7 D6 D5 D4 D3 D2 D1 D0 [EMG] [ALARM] [LMT+] [LMT+] [IN3] [IN2] [IN1] [IN0] [ADSND] [ACNST] [AASND] [DSND] [CNST] [IASND] [CMP-] [CMP+]
0	1	0	XRR2 YRR2 ZRR2 URR2	X axis status register 2 Y axis status register 2 Z axis status register 2 U axis status register 2	Displaying the error information and the state of automatic home search. D15 D14 D13 D12 D11 D10 D9 D8 D7 D6 D5 D4 D3 D2 D1 D0 [-] [0] [0] [HMST4] [HMST3] [HMST2] [HMST1] [HMST0] [HOME] [0] [EMG] [ALARM] [HLMT] [HLMT+] [SLMT] [SLMT+]
0	1	1	XRR3 YRR3 ZRR3 URR3	X axis status register 3 Y axis status register 3 Z axis status register 3 U axis status register 3	Displaying the factor of interrupt occring (interpolation excluded). D15 D14 D13 D12 D11 D10 D9 D8 D7 D6 D5 D4 D3 D2 D1 D0 [-] [-] [-] [-] [-] [-] [-] [-] [SYNCH] [MEND] [D-END] [C-STA] [C-END] [P<C+] [P<C+] [P<C+] [P<C+] [PULSE]
1	0	0	RR4	Input register 1	Displaying the input signal status of X and Y axis. D15 D14 D13 D12 D11 D10 D9 D8 D7 D6 D5 D4 D3 D2 D1 D0 [Y-ALMY] [INPY-EX] [Y-EX+] [Y-IN3] [Y-IN2] [Y-IN1] [Y-IN0] [X-ALM] [X-INP] [X-EX-] [X-EX+] [X-IN3] [X-IN2] [X-IN1] [X-IN0]
1	0	1	RR5	Input register 2	Displaying the input signal status of Z and U axis. D15 D14 D13 D12 D11 D10 D9 D8 D7 D6 D5 D4 D3 D2 D1 D0 [U-ALM] [U-INP] [U-EX-] [U-EX+] [U-IN3] [U-IN2] [U-IN1] [U-IN0] [Z-ALM] [Z-INP] [Z-EX-] [Z-EX+] [Z-IN3] [Z-IN2] [Z-IN1] [Z-IN0]
1	1	0	RR6	Read data register 1	Displaying the low word 16-bit for the read data.(D15~D0)
1	1	1	RR7	Read data register 2	Displaying the low word 16-bit for the read data.(D31~D16)

Data writing commands

The above table indicates the address for 16-bit data bus. In 8-bit bus access, the 16bit data bus are divided into the high word byte (D15~8) and the low word byte (D7~0). Each axis has RR1,RR2 and RR3 (status register 1,2 and 3). It can be read the data in these registers by the same address. It depends on the axis assignment of the last command to read the data in the mode register of which axis. Or, user can select the axis by writing the NOP command which is assigned an axis just before.

Code	Setting Command	Symbol	Data range	Data length (byte)
00	Range	R	R8,000,000(multiple=1) ~ 16,000(=500)	4 bytes
01	Jerk	K	1 ~ 65,535	2
02	Acceleration	A	1 ~ 8,000	2
03	Deceleration	D	1 ~ 8,000	2
04	Initial speed	SV	1 ~ 8,000	2
05	Drive speed	V	1 ~ 8,000	2
06	Output pulse numbers	P	Output pulse numbers:0 ~ 268,435,455	4
	Interpolation finish point		Finish point:-2,147,483,646~+2,147,483,646	4
07	Manual deceleration point	DP	0 ~ 4,294,967,295	4
08	Center point of circulate	C	-2,147,483,646 ~ +2,147,483,646	4
09	Logical position counter	LP	-2,147,483,648 ~ +2,147,483,647	4
0A	Real point counter	EP	-2,147,483,648 ~ +2,147,483,647	4
0B	COMP+ register	CP	-2,147,483,648 ~ +2,147,483,647	4
0C	COMP- register	CM	-2,147,483,648 ~ +2,147,483,647	4
0D	Acceleration counter offset	AO	-32,768 ~ +32,767	2
0E	Increase of deceleration	L	1 ~ 65,535	2
60	Expansion mode	EM	(Bit data)	2
61	Home search speed	HV	1 ~ 8,000	2
64	Synchronous action mode	SM	(Bit data)	4

Data reading commands

Code	Reading Command	Symbol	Data range	Data length (byte)
10	Logical position counter	LP	-2,147,483,648~+2,147,483,647	4 bytes
11	Real position counter	EP	-2,147,483,648~+2,147,483,647	4
12	Current drive speed	CV	1 ~ 8,000	2
13	Acceleration / deceleration	CA	1 ~ 8,000	2
14	Synchronous buffer register	SB	-2,147,483,648~+2,147,483,647	4

Driving commands

Code	Commands
20	+direction fixed pulse drive
21	-direction fixed pulse drive
22	+direction continuous drive
23	-direction continuous drive
24	drive start holding
25	drive start holding release
26	/termination status clear
27	decelerating stop
	instant stop

Interpolation commands

Code	Commands
30	2-axis linear interpolation
31	3-axis linear interpolation
32	CW circulate interpolation
33	CCW circulate interpolation
34	2-axis bit pattern interpolation
35	3-axis bit pattern interpolation
36	BP register writable
37	BP register unwritable
38	BP data stack
39	BP data clear
3A	1 step interpolation
3B	deceleration enable
3C	deceleration disable
3D	interpolation interrupt clear

*BP= bit pattern

Other commands

Code	Commands
62	Automatic home search execution
63	Deviation counter clear output
65	Synchronous action activation
0F	NOP (for axis switching)

Parameter calculation

at CLK= 16MHz
 $Multple(M) = \frac{8,000,000}{R} \times \frac{Accelerating\ speed(PPS/SEC)}{K} = \frac{62.5 \times 10^6}{K} \times M$
 $Decelerating\ speed(PPS/SEC) = \frac{62.5 \times 10^6}{L} \times M$
 Accelerating speed(PPS/SEC)=A×125×M Drive speed(PPS)=V×M
 Decelerating speed(PPS/SEC)=D×125×M Initial speed(PPS)=SV×M

The Specifications are subject to change without notice due to the technical development. 2011.2

Distributor



达格美 (上海) 集成电路有限公司
TAKUMI (SHANGHAI) INTEGRATED CUIUIT CO.,LTD.

地址: 上海市浦东新区张杨路188号汤臣中心B栋801室
 电话: 021-5840-8299 E-mail: dgms@takumi-hkg.com
 传真: 021-5840-1590 WEB: www.takumi-sh.com



NOVA electronics, Inc.

3F, Grand Axe Bldg., 1-7-20 Uehara, Shibuya-Ku, Tokyo 151-0064, Japan
 WEB SITE http://www.novaelec.co.jp/eng/index.html
 EMAIL ADDRESS novaelec_info@novaelec.co.jp
 TEL 81-3-5738-3666 FAX 81-3-5738-3665